



Samsung Date and Time Change

This must be done from an LCD display phone only

- Leave the handset down
- Press TRSF 200
- Enter Pass code 1234
- Speaker 505
- Display shows: New:Wmmddy: Hhmm
- Enter new details as follows:

W = Day of the week (1 7) with 1 being Monday

Mm = Month (1 12)

Dd = Day of the Month (1 31)

Yy = Last 2 digits of the year

Hhmm = Time in 24 hour format